

NOTE: ESATTO software package 3

EN

If you update from previous version, please install “PLAY” software first (you can find in the DOWNLOAD section of our website www.primalucelab.com) and update ESATTO firmware to the latest version by following instructions in the ESATTO user manual 3.

Please note:

- 1) **Firmware 3 adds support to ARCO rotator: please update your ESATTO firmware by using PLAY.** ARCO can't be used with ESATTO if it still has previous firmware version, if it is used with the previous FOCUSER Manager software and if you're using previous version ASCOM driver.
- 2) **Starting from firmware 3.0, ESATTO has to be used with “PLAY” software that replaces “FOCUSER Manager”.** If you use FOCUSER Manager with an ESATTO with firmware 3.0, you can't control ARCO rotator.
- 3) **Starting from firmware 3.0, if you want to control ESATTO with third party softwares, you have to uninstall the older ASCOM drivers and install the new “PLL ASCOM Focuser” version 3 (and ASCOM platform at least 7).** Previous version ASCOM drivers do not offer all the features of the new ones.

ITA

Se aggiornate da una versione precedente, installate prima il software “PLAY” (lo trovate nella sezione DOWNLOAD del nostro sito www.primalucelab.com) e aggiornate il firmware di ESATTO all'ultima versione seguendo le istruzioni del manuale 3 di ESATTO.

Nota:

- 1) **Il firmware 3 aggiunge il supporto al rotatore ARCO: aggiornate il firmware del vostro ESATTO utilizzando PLAY.** ARCO non può essere usato con ESATTO dotato di una precedente versione del firmware, se viene usato con il precedente software FOCUSER Manager e se state utilizzando la versione precedente dei driver ASCOM.
- 2) **A partire dal firmware 3.0, ESATTO deve essere usato con il software “PLAY” che sostituisce “FOCUSER Manager”.** Se utilizzate FOCUSER Manager con ESATTO con firmware 3.0, non potete controllare il rotatore ARCO.
- 3) **A partire dal firmware 3.0, se volete controllare ESATTO con software di terze parti, dovete prima disinstallare la precedente versione dei driver ASCOM e installare la nuova versione 3 dei driver “PLL ASCOM Focuser” (e piattaforma ASCOM almeno 7).** Precedenti versioni dei driver ASCOM non offrono tutte le caratteristiche di quelli nuovi.