

## NOTE: SESTO SENSO 2 software package 3

### EN

If you update from previous version, please install “PLAY” software first (you can find in the DOWNLOAD section of our website [www.primalucelab.com](http://www.primalucelab.com)) and update SESTO SENSO 2 firmware to the latest version by following instructions in the SESTO SENSO 2 user manual 3.

Please note:

- 1) **Firmware 3 adds support to ARCO rotator: please update your SESTO SENSO 2 firmware by using PLAY.** ARCO can't be used with SESTO SENSO 2 if it still has previous firmware version, if it is used with the previous FOCUSER Manager software and if you're using previous version ASCOM driver.
- 2) **Starting from firmware 3.0, SESTO SENSO 2 has to be used with “PLAY” software that replaces “FOCUSER Manager”.** If you use FOCUSER Manager with a SESTO SENSO 2 with firmware 3.0, you can't control ARCO rotator.
- 3) **Starting from firmware 3.0, if you want to control SESTO SENSO 2 with third party softwares, you have to uninstall the older ASCOM drivers and install the new “PLL ASCOM Focuser” version 3 (and ASCOM platform at least 6.4).** Previous version ASCOM drivers do not offer all the features of the new ones.

### ITA

Se aggiornate da una versione precedente, installate prima il software “PLAY” (lo trovate nella sezione DOWNLOAD del nostro sito [www.primalucelab.com](http://www.primalucelab.com)) e aggiornate il firmware di SESTO SENSO 2 all'ultima versione seguendo le istruzioni del manuale 3 di ESATTO.

Nota:

- 1) **Il firmware 3 aggiunge il supporto al rotatore ARCO: aggiornate il firmware del vostro SESTO SENSO 2 utilizzando PLAY.** ARCO non può essere usato con SESTO SENSO 2 dotato di una precedente versione del firmware, se viene usato con il precedente software FOCUSER Manager e se state utilizzando la versione precedente dei driver ASCOM.
- 2) **A partire dal firmware 3.0, SESTO SENSO 2 deve essere usato con il software “PLAY” che sostituisce “FOCUSER Manager”.** Se utilizzate FOCUSER Manager con SESTO SENSO 2 con firmware 3.0, non potete controllare il rotatore ARCO.
- 3) **A partire dal firmware 3.0, se volete controllare SESTO SENSO 2 con software di terze parti, dovete prima disinstallare la precedente versione dei driver ASCOM e installare la nuova versione 3 dei driver “PLL ASCOM Focuser” (e piattaforma ASCOM almeno 6.4).** Precedenti versioni dei driver ASCOM non offrono tutte le caratteristiche di quelli nuovi.